

Apex Industrial Electronics

symbol of quality





Perimeter



Perimeter is used to measure the peripheral field vision. The apparatus comprises of a calibrated arc, revolving chart holder. The object carrier which moves over the arc, contains five colours and five aperture of different diameter, calibrated scale. At the back of the arc arrangement is provided for fixing of chart which has concentric circles corresponding to the degrees of arc Perimeter has adjustable chin rest. All fitted over a sturdy base with receptacle for keeping charts. For table top use. Complete with 100 charts.

Types:-

- Priestly Smith Type
- Priestly Lister Type

5375, Cross Road No. 1, Ambala Cantt-133001 (Haryana) - India

Phone Number: +91 171-4005686, Mobile: +91-9416966084, 9896055375 Email ID: apexambala@gmail.com, apexambala@rediffmail.com

Website: www.aie-india.com